

# US Slatwall

## 1" Aluminum Hidden Fastener Installation Instructions

Start at the bottom. If studs are concealed under a substrate, you must first locate and mark stud locations. We recommend attachment every 16" on-center. Slatwall can be installed over wood or steel studs.

- A.** Laser or snap a **level** reference line at the **bottom** of your entire slatwall area. Double check to make sure the total number of slatwall pieces will fit your desired slatwall area including J-Cap top & bottom. (i.e. 6 pieces x 6" + 1" = 37")

Place the hidden fastener J-Cap with the bottom aligned to your level line and attach with screws. J-Cap must be straight and level. Do not space screws greater than 16" apart and use maximum size #10 pan head screw. Screws should be centered in small groove on trim. Pre-drill if necessary. Place the first slatwall piece onto the J-Cap making sure it is level and seated as shown in **A2**.

- B.** Once seated correctly, attach each piece with screws at the top as shown in **B1**. Do not space screws greater than 16" apart. Repeat the procedure with additional pieces, making sure each is seated as shown in **B2** and secured at the top with screws. Continue to the top of your slatwall area until all pieces are installed. Always check level and fit of each piece.

- C.** At top of slatwall, attach a piece of hidden fastener J-Cap onto the topmost piece. A small amount of adhesive may be used on the top flange to secure the J-Cap in place.

**Caution: Improper installation will cause accessory problems and uneven walls.**

